

SERIE E

PARTS	DESCRIPTION
A-TR-00-B	INSERT TRIGGER
A-TR-01-B	SIMPLE TRIGGER
A-TR-02-B	DOUBLE TRIGGER
AD-04-324L-SERIE E	BOOT ADAPTER SERIE E
BU-00SS	BUSHING SET SCREWS
E-FP-00-B	BLANK FACEPLATE
E-FP-01-B	EMPTY FACE PLATE
E-FP-02-RK1PR.	FACEPLATE 2 BOUTTON OR 1 PROPORLTINAL
E-FP-2RK1PR	FACEPLATE 2 PROPORTIONAL
E-FP-RK1PR	FACEPLATE 1 PROPORTIONAL
E-FP-RK3MA-02-B	FACEPLATE ROCKER SWITCH OR 2 LED
E-HL-01-B	HANDLE CASE LEFT
E-HL-02-B	HANDLE CASE RIGHT
E-ME-A1-B	1 BUTTON OVERLAY
E-ME-A2-B	2 BUTTON OVERLAY
E-ME-A4-B	4 BUTTON OVERLAY
LED	LED(GREEN OR RED)
LS-00	LEAF SPRING
PN-03X	MOUNTING PIN
RK-1PR	PROPORTIONAL
RK-3MADPDT	ROCKER SWITCH
SC-03	TAPPING SCREW #2X7/16"
SC-04	VIS ALLEN 10-32X1/4
SW-00	SWITCH SURE GRIP 5 AMP

